

Specimen Radiography System



QUICK START GUIDE

1. POWER UP

- Ensure the power switch on the back of the Faxitron
 CT system is set to the ON position
- Press the grey "On/Off" button on the front of the Faxitron CT system
- Turn the monitor **on** (if needed)

2. START SOFTWARE

- Verify there is nothing in the Faxitron CT x-ray chamber
- Double click the "Faxitron CT" icon in the center of the desktop and enter password

3. CALIBRATE

 You will be prompted to calibrate once you log in Press the "Image Calibrate" button to proceed

4. PATIENT DATA

- Start Procedure
- · Select from Worklist
- · Locate patient's name and double click it
- Enter any missing required fields such as Laterality
- "Accept"

5. X-RAY IMAGING

- Place specimen in one of the disposable CT Trays provide with the sysetm
 - (A package of 10 disposable CT Trays was provided with your system. Please refer to the CT Trays packaging for information on ordering replacement trays)
- Place the specimen and tray on the pedestal
- Select "3D" mode in the lower right corner
- Press the green "X-ray" button to activate x-rays
 - image will appear after a few seconds

6. IMAGE MANIPULATION

- Click on the "Play" button in any of the slice views to automatically scroll through the slice
- Hold down the left trackball button to rotate the 3D view

7. STORING TO PACS

• Choose "PACS Store" button on left side of screen

8. SHUT DOWN

- Return to the Home Menu (or Start-up Screen) and Select the "Shutdown" button
- Click the "Okay" button to Continue with shutdown

www.hologic.com/package-inserts



Hologic, Inc. 600 Technology Drive Newark, DE 19702 USA 1.800.447.1856 www.hologic.com